LAVAMAT 86810

Washing machine

User information

PERFEKT IN FORM UND FUNKTION

AEG

Electrolux

Downloaded From WashingMachine-Manual.com Manuals

Dear customer,

Please read this User Information carefully and keep it to refer to at a later date.
Pass this User Information on to any subsequent owner of the appliance.

The following symbols are used in the text:

Safety instructions
Warning: Notes that concern your personal safety.
Attention: Notes that show how to avoid damage to the appliance.

Useful tips and hints

Environmental information

Downloaded From WashingMachine-Manual.com Manuals

Contents

Operating Instructions 5

Safety 5

Description of the appliance 7
Control panel 7
What is shown in the display 7

Program overview 8

Prior to using for the first time 10
Switching on the appliance for the first time - setting the language. 10
Setting the time. 11
Carrying out a wash program prior to first use 11

Preparing and sorting washing 11

Running a washing cycle 12
Opening the door/loading washing 12
Adding detergent/additives 12
Switching on the appliance/selecting a program. 13
Changing the temperature 14
Changing spin speed/selecting rinse hold 14
Setting options. 14
Prewash, Sensitive, Stain, Night Cycle 15
Setting times 16
Time Saving: SHORT or VERY SHORT 16
Delay Start 17
Starting a program 18
Program progress 18
Washing cycle complete/Removing the washing 18

Setup 19
Memory 1, 2, 3 19
Volume 20
Extra Rinse 21
Language 21
Clock 22
Contrast and brightness 22

Child safety device 23

Cleaning and maintenance 23

What to do if... 25
Remedying small malfunctions yourself 25

Downloaded From WashingMachine-Manual.com Manuals

If the wash results are not satisfactory 27
Carrying out an emergency drain 28
Drain pump 29

Disposal 30

Technical data 31

Consumption values 31

Installation and connection instructions 32

Safety information for the installation 32

Installing the appliance 33
Transporting the appliance 33
Unpacking 33
Where to install 36
Making the appliance level 36

Electrical connection 36

Connecting to the water supply 37
Water inlet 37
Water drainage 39

Guarantee/Customer Service 40

Service 43

Downloaded From WashingMachine-Manual.com Manuals

⚠ Safety

Prior to using for the first time

- Follow the **"Instructions for installation and connection"**.
- If the appliance is delivered in the winter months when there are minus temperatures: Store the washing machine at room temperature for 24 hours before using for the first time.

Correct use

- The washing machine is only designed for the washing of normal domestic laundry at home.
- Additions or modifications to the washing machine are not permitted.
- Use only detergents and additives that are suitable for use in domestic washing machines.
- The washing must not contain any inflammable solutions. Danger of explosion!
- Do not use the washing machine for dry cleaning.
- Dyes/colour removers may only be used in the washing machine, if the manufacturer of these products expressly permits this. We cannot be held responsible for any damage arising.

Child safety

- Keep packaging away from children. There is a risk of suffocation.
- Children often do not recognise the hazards associated with electrical appliances. Do not allow children to use the washing machine unsupervised.
- Make sure that children and pets don't climb into the drum of the washing machine. Could endanger life!

Downloaded From WashingMachine-Manual.com Manuals

General safety

- Repairs to the washing machine must only be carried out by qualified service engineers.
- Never use the washing machine if the mains cable is damaged; or if the control panel, work top or plinth area is damaged such that the inside of the appliance is freely accessible.
- Switch off the washing machine before cleaning, maintenance and servicing. In addition, pull the mains plug out of the socket or – in the case of a permanent connection – switch off the cut-out in the fuse box or remove the screw fuse completely.
- If operation is stopped, disconnect the appliance from the mains supply and shut off the water tap.
- Never unplug the appliance by pulling on the cable. Always pull the plug.
- Multi-way plugs, connectors and extension cables must not be used. **This could constitute a fire hazard through overheating.**
- Never wash the washing machine down with a water jet. Danger of electric shock!
- In washing programmes with high temperatures the glass in the door gets hot. Do not touch it.
- Before emergency emptying of the appliance, before cleaning the drain pump or opening the door in an emergency, let the water cool down.
- Small animals can nibble at the cables and water hoses. Danger of electric shock and danger of water damage! Keep small animals away from the washing machine.

Downloaded From WashingMachine-Manual.com Manuals

Description of the appliance



Control panel



What is shown in the display



Downloaded From WashingMachine-Manual.com Manuals

Program overview

Program	max. load[1] (dry washing)	Options				Times			Spin speed			
		PREWASH	SENSITIVE	STAIN	NIGHT CYCLE	SHORT	VERY SHORT	DELAY START	1600/1400	1200/1000/800/600/400	0	RINSE HOLD
ECO ENERGY SAVING [2]	6 kg	•	•	•	•			•	•	•	•	•
95 COTTON	6 kg	•	•	•	•	•[3]	•[3]	•	•	•	•	•
LINEN/EASY-CARES 60°, 50°, 40°, 30°, Cold cycle	6 kg or 3 kg	•	•	•[4]	•	•[3]	•[3]	•	•	•	•	•
40 - 60 MIX	6 kg	•	•	•	•			•	•	•	•	•
DELICATE 40°, 30°, Cold cycle	3 kg	•		•[4]	•		•	•		•	•	•
WOOL/(HANDWASH) 40°, 30°, Cold cycle	2 kg							•		•	•	•
SILK/(HANDWASH)	1 kg							•		•	•	•
SPIN	6 kg								•	•		
RINSE	3 kg							•		•	•	•
DRAIN												
REFRESH	3 kg							•		•	•	•
EASY IRON 40	1 kg	•		•	•	•	•	•		•	•	•

1) A 10 litre bucket holds around 2.5 kg of dry washing (cotton)
2) Program settings for testing in accordance with or in support of EN 60 456 and IEC 60 456 are described in the Chapter "Consumption Values".
3) Recommended load for short progammes is 3 kg; full loading is possible however with somewhat reduced cleaning results.
4) STAIN can only be selected with wash temperatures of 40°C and above, as stain treatment products are only effective at higher temperatures.

Downloaded From WashingMachine-Manual.com Manuals

Use/Features	Care symbols[1)]
Energy-saving program at 60 °C for lightly to normally soiled whites/coloureds made of cotton/linen.	
Program at 95 °C for normally to heavily soiled whites/coloureds made of cotton/linen.	
General program for whites/coloureds made of cotton/linen as well as for easy-care mixed fibres and synthetics. The program is automatically adjusted to the different fabric types and load sizes. If loading only with easy-care washing, do not load more than 3 kg.	
Program for whites/coloureds which are labelled for different wash temperatures. Items, which according to the care symbols are normally to be washed separately at 40 °C or at 60 °C, can be washed together in this program. Achieves the washing results of a normal 60° programme.	
Gentle program for delicate fabrics such as bonded fabrics, microfibres, synthetics, net curtains (max. net curtain load 20 to 25 m^2). If used with RINSE HOLD also suitable for items with a climatic membrane, e.g. outdoor clothing.	
Particularly delicate program for machine washable and hand washable wool or wool mixtures.	
Particularly delicate program at 30 °C, for machine washable and hand washable silk. Wash very delicate items individually.	
Draining and spinning, e.g. after a RINSE HOLD/ NIGHT CYCLE, or separate spin for hand-washed cottons/linens and easy-cares.	
Separate gentle rinse (3 rinses, liquid conditioner is washed in from compartment, gentle spin).	
Pumps water away after a RINSE HOLD.	
Special cycle at 30 °C, about 20 minutes long, for quickly washing through e. g. once worn, slightly dirty sports clothing or new clothes.	
Special cycle at 40 °C for easy-care fabrics, which afterwards are to be ironed only lightly or not at all.	

1) The numbers in the care symbols show the maximum temperatures.

Downloaded From WashingMachine-Manual.com Manuals

Prior to using for the first time

Switching on the appliance for the first time - setting the language

The display is set to English as standard in the factory.

Important: If the display does not show the menu for setting the language when the appliance is switched on, the appliance has been switched on before. If this happens, please see the section "Setup/Language".

To switch on the appliance, turn the program knob to any program, e. g. \95/ COTTON.

The display lights up and should look like the illustration opposite.
In addition the display shows:
– "To confirm push OK key"
– "To change push OPTION key"

If you want to keep the language:

Press the OK key.

If you want to change the language:

1. Press the 🕮 OPTION key repeatedly, until the desired language appears in the display, e. g. DEUTSCH.
2. Press the OK key.

In the display DEUTSCH flashes several times and the display should then look like e.g. the illustration opposite.

3. To switch the appliance off, turn the programme knob to ◯ OFF.



Downloaded From WashingMachine-Manual.com Manuals

Setting the time

So that the time and the end of the program are correctly displayed, please check the display and set the current time if necessary. To do this, please see the section "Setup/Clock".

Carrying out a wash program prior to first use

In order to remove any residues from the drum and water container which may have been left during manufacturing, perform the first wash cycle without any washing in the machine. Program: LINEN/EASY-CARES 60 °C, option TIME SAVING: VERY SHORT, use approx. 1/4 measuring cup of detergent.

Preparing and sorting washing

Preparing washing

- Empty pockets. Remove foreign bodies (e. g. coins, paper clips, nails, etc.).
- Do up zips, button up covers to prevent damage to washing.
- Remove the runners from net curtains or cover them with a net or a bag.
- Wash sensitive and small items in a net or a pillow case, e.g. net curtains, tights, socks, handkerchiefs, bras.

Important! Bras and other items containing wires should NOT be washed in this washing machine.

Sorting washing

- By colour: Wash white and coloured washing separately. Washing can run.
- By temperature, type of washing and care symbol.

Important! Do not wash fabrics with care symbol (= do not wash!) in the washing machine.

Downloaded From WashingMachine-Manual.com Manuals

Running a washing cycle

Opening the door/loading washing

1. To open the door: pull the door by the handle.
2. Unfold washing and load it loosely into the machine. Mix large and small items.
   Important: Do not get any washing caught between the door and the rubber seal.
3. Push the door shut firmly. Door catch must audibly click shut.



Adding detergent/additives

Important: Use only detergents and additives that are suitable for use in domestic washing machines.

For USA and Canada only!

Important! Only LOW-SUDSING detergent suitable for a front-loading washing machine can be used in this machine. This machine can heat the water up to 95 degrees celsius, or 200 degrees fahrenheit, and care should be taken to ensure that the correct washing powder is used. If you have any doubt, check with your dealer or the distributor.

WARRANTY AND CONSEQUENTIAL DAMAGES ARE VOIDED IF A LOW SUDSING DETERGENT IS NOT USED.

Dose detergent and additives according to the instructions of the detergent and additive manufacturers. Follow the instructions on the packaging.

Dosing depends upon:
– the washing's degree of soiling,
– the size of the load
– the degree of hardness of the water supply.

- If the manufacturer does not give instructions for small loads: for a half load, use a third less, for a very small load, use only half of the detergent that is recommended for a full load.
- From water hardness 2 (= medium) upwards, water softener should be used. Detergent can then always be dosed for water hardness 1 (= soft). Your local water company will be able to give you information about the water hardness in your area.

Downloaded From WashingMachine-Manual.com Manuals

1. Pull the detergent dispenser drawer out as far as the stop.
2. Add the detergent/additives.
3. Push the drawer in fully.


Washing powder/tablets for the main wash
Softeners/ wash-care products to preserve the shape of garments/ starch
In-wash stain treatment/ tablets
Washing powder/tablets for the pre-wash or for water softener

Washing powder/tablets for the main wash

If you are using water softener and need the right-hand compartment for the pre-wash detergent, add the water softener to the main wash detergent in the left-hand compartment.

Softeners, wash-care products to preserve the shape of garments, starch

Do not fill the compartment beyond the MAX mark. Dilute thick liquid concentrates according to the manufacturer's instructions before putting them into the drawer. Dissolve powder starches.

If you use liquid detergents:

Add liquid detergent using the dosage container provided by the detergent manufacturer and place on top of the washing drum.

Switching on the appliance/selecting a program

Select the program using the program knob, e.g., LINEN/EASY-CARES.



By selecting a program, you switch the appliance on at the same time.

– The display lights up and shows the program set, the current time and the estimated end of the cycle.
– Depending on the program, the washing machine suggests a temperature and a spin speed. You can change these suggestions.

Downloaded From WashingMachine-Manual.com Manuals

– The lighting for the display switches itself off at the end of the cycle or, if the appliance is not started after the program is set, after 10 minutes. To switch the light on again, press any key or turn the program knob.

Changing the temperature

Press the TEMPERATURE key repeatedly until the desired temperature is displayed.

Changing spin speed/selecting rinse hold

Press the RPM key repeatedly, until the desired spin speed or RINSE HOLD is displayed.

With spin speed "0" the last rinse water is drained off at the end of the cycle, but the washing is not spun.

- With RINSE HOLD the washing is left to soak in the last rinse water. There is no final spin after the intermediate spin(s). Intermediate spins are programme-dependent and cannot be altered.

Setting options

Options can be added to a wash cycle that has already been selected. Press the OPTION key. The display shows the symbols for the options.

PREWASH

Pre-washes at about 30 °C before the main wash cycle, which follows automatically.

Downloaded From WashingMachine-Manual.com Manuals

SENSITIVE

Enhanced rinse action through an additional rinse cycle together with decreased drum movement (improved fabric care). This is ideal when frequent washes are necessary, for example, in cases of highly sensitive skin. An additional rinse cycle can also be permanently set (see section "Setup").

STAIN

For heavily soiled and stained washing. In-wash stain treatment products are washed in at the optimum time as the program progresses.

NIGHT CYCLE

The washing is left to soak in the final rinse water. There is no final spin and no intermediate spin. Because of this the program runs very quietly. NIGHT CYCLE is therefore particularly suitable if you want to wash at night.

SETUP

The special functions that can be set under Setup remain permanently stored in the appliance, e. g., time, language, etc. (see section "Setup") until they are changed or deactivated.

Only the options that can be combined with the cycle that has already been set are shown in the display.

Prewash, Sensitive, Stain, Night Cycle

1. Press the OPTION key repeatedly until the desired symbol flashes, e. g., PREWASH (With each press of the key, the next symbol flashes, from left to right.)

2. Press the OK key. The symbol stops flashing. A black bar appears under the symbol. The option is set. The display changes to the next option.
To switch off the option, press the OPTION key

Downloaded From WashingMachine-Manual.com Manuals

repeatedly until the symbol for the option flashes and then press the OK key. The black bar under the symbol disappears.

If other options are to be selected: Press the 📖 OPTION key repeatedly until the desired symbol flashes and confirm each one with the OK key.

3. Press the 📖 OPTION key repeatedly, until your program set appears again. The display shows the symbol for the selected option.

Setting times

Shortened cycles and the delay of the start time can be set for a wash cycle that has already been selected.

Press the 🕓 TIME key. The display shows the symbols for TIME SAVING and DELAY START.

→| TIME SAVING: SHORT or VERY SHORT

Shortened wash cycle for lightly soiled washing.

– SHORT: only possible with the programs COTTON, LINEN/EASY-CARES and EASY IRON
– VERY SHORT: only possible with the programs COTTON, LINEN/EASY-CARES and EASY IRON and DELICATE.

🕓 DELAY START

To delay the start of a program by between 30 minutes and a max. of 20 hours.

Time Saving: SHORT or VERY SHORT

1. Press the 🕓 TIME key repeatedly, until the TIME SAVING symbol →| flashes.
2. Press the OK key.
3. Press the 🕓 TIME key. A black bar appears under the →| TIME SAVING symbol, SHORT or VERY SHORT appears in the display.

Downloaded From WashingMachine-Manual.com Manuals

4. To change from SHORT to VERY SHORT, press the ⏲ TIME key again.

ⓘ You can change between NORMAL, SHORT, and VERY SHORT using the ⏲ TIME key.

5. Press the OK key to confirm the selection. The display changes to the symbol for ⏲ DELAY START, i.e. DELAY START can now be set.
6. Press the ⏲ TIME key, if no Delay Start is to be set. The display shows the TIME SAVING symbol →| as well as the time for the end of the cycle.

Delay Start

1. Press the ⏲ TIME key repeatedly, until the DELAY START symbol ⏲ flashes.
2. Press the OK key. In the display, "Start in 0 min" is displayed.
3. Press the ⏲ TIME key repeatedly, until the display shows the desired period by which you want to delay the start, e. g. "Start in 4h" (=4 hours). A black bar appears under the ⏲ DELAY START symbol.

ⓘ If 20 h is displayed and you press the key again, the delayed start is cancelled.

4. Press the OK key. The display shows the ⏲ DELAY START and the time until the end of the program (including period by which the start has been delayed).
5. To activate the Delay Start, press the ⏵⏷ START/PAUSE key. The display now shows e. g., "Start in 4.00" (=4 hours). The display for the time remaining until the start of the program is reduced in 30 minute intervals (e.g., 4.00, 3.30, 3.00, ... 0.30, 0).

Downloaded From WashingMachine-Manual.com Manuals

Starting a program

1. Check that the water tap is open.
2. Press the ⏵⏷ START/PAUSE key.
   The program is started or it starts after the time delay set has elapsed.

If after pressing the ⏵⏷ START/PAUSE key the display shows "Door not Closed", the door has not been shut properly. Push the door firmly closed and press the ⏵⏷ START/PAUSE key again.

Program progress

The display indicates the stage of the program that is currently being performed as well as the time of the end of the program.

During the washing cycle the time of the end of the program may change as the program adjusts itself to different conditions (e. g., type and quantity of laundry, out of balance spin detection, special rinses, etc.).

Washing cycle complete/Removing the washing

At the end of the cycle a long acoustic signal sounds 3 times (when the SOUND setting is NORMAL or LOW) and the messages "Cycle ended" and "Door openable" appear alternately in the display.

1. Open the door and remove the washing.
2. Turn the programme knob to ◯ OFF.
3. After the wash, pull out the detergent dispenser drawer slightly to allow it to dry. Leave the door slightly open to air the inside of the washing machine.

If RINSE HOLD or NIGHT CYCLE was selected:
After a RINSE HOLD or when a program with NIGHT CYCLE has ended, the ⏵⏷ START/PAUSE indicator flashes. "Cycle ended" and "Door locked" appear alternately in the display.

The water must first be drained:

– Turn the programme knob to ◯ OFF, then to DRAIN and press the ⏵⏷ START/PAUSE key (the water is drained without spinning), or

Downloaded From WashingMachine-Manual.com Manuals

– or turn the programme knob to ◯ OFF and then to SPIN. Change the spin speed if necessary and press the START/PAUSE key (the water is drained and the washing spun).

Setup

The special functions that can be set under Setup remain permanently stored independent of each washing cycle – even after the appliance has been switched off or the mains plug has been removed from the socket.

Memory 1, 2, 3

Program combinations can be stored at program knob positions MEMORY 1, 2, 3 and can then be selected directly using the program knob. To do this the desired program combination is first put together and then stored.

Setting the Memory

Example: Program position MEMORY 1 is to be given the following program combination: LINEN/EASY-CARES 40 °C, 800 rpm, with PREWASH.

1. Turn the program knob to LINEN/EASY-CARES.
2. Press the TEMPERATURE key repeatedly, until 40 °C appears in the display.
3. Press the RPM key repeatedly, until 800 appears in the display.
4. Using the OPTION key set PREWASH and press the OK key. A black bar appears under the PREWASH symbol.
5. Press the OPTION key repeatedly, until the SETUP symbol flashes.
6. Press the OK key. The display changes to the Special Functions level. Program memory position MEMORY 1 is offered first.

To change to another memory position, press the OPTION key.

Downloaded From WashingMachine-Manual.com Manuals

7. Press the OK key.
   The program combination is now stored to program knob position MEMORY 1 and in the future can be selected directly using the program knob.

The Memory can be overwritten at any time with a new program combination (see "Changing the Memory") but cannot be deleted.

Changing the Memory

1. Put together the new program combination as required (for an example, see "Setting the Memory", steps 1 to 4).
2. Press the OPTION key repeatedly, until the SETUP symbol flashes.
3. Press the OK key.
4. Using the OPTION key select the memory position to be changed, e. g. MEMORY 1.
5. Store the new program combination using the OK key.

Volume

The volume of the acoustic signal can be selected.

1. Turn the program knob to any program and press the OPTION key repeatedly until the SETUP symbol flashes.
2. Press the OK key.
3. Press the OPTION key repeatedly, until VOLUME is shown in the display.
4. Press the OK key.
5. Press the OPTION key repeatedly until the desired volume (NORMAL, LOW, NO SOUND) is shown in the display.
6. Press the OK key to confirm the setting. The icon changes to the next special function.



7. Press the OPTION key repeatedly until your program set appears again.

Downloaded From WashingMachine-Manual.com Manuals

Extra Rinse

1. Turn the program knob to any program and press the OPTION key repeatedly until the SETUP symbol flashes.
2. Press the OK key.
3. Press the OPTION key repeatedly until +RINSE+ is shown in the display.
4. Press the OK key. The RINSE+ symbol +RINSE+ appears. The display changes to the next special function.



5. Press the OPTION key repeatedly, until your program set appears again.

Language

1. Turn the program knob to any program and press the OPTION key repeatedly until the SETUP symbol flashes.
2. Press the OK key.
3. Press the OPTION key repeatedly, until the display shows LANGUAGE.
4. Press the OK key.
5. Press the OPTION key repeatedly, until the desired language appears in the display, e. g. DEUTSCH.
6. Press the OK key. The display changes to the next special function.
7. Press the OPTION key repeatedly, until your program set appears again.

Downloaded From WashingMachine-Manual.com Manuals

Clock

1. Turn the program knob to any program and press the OPTION key repeatedly until the SETUP symbol flashes.
2. Press the OK key.
3. Press the OPTION key repeatedly until CLOCK is shown in the display.
4. Press the OK key.
5. Using the OPTION key set the desired time. With each press of the key, the display moves on by one minute. Keeping the key depressed changes the display in 10 minute steps.

6. Press the OK key. The display changes to the next special function.
7. Press the OPTION key repeatedly, until your program set appears again.

Contrast and brightness

1. Turn the program knob to any program and press the OPTION key repeatedly until the SETUP symbol flashes.
2. Press the OK key.
3. Press the OPTION key repeatedly, until the display shows CONTRAST or or BRIGHTNESS.
4. Press the OK key.
5. Using the OPTION key set the desired setting. With each press of the key or if the key is kept pressed down, the black triangle in the diagram moves further to the right for more contrast or brightness. If the triangle reaches the right hand edge, it starts again from the left.



6. Press the OK key. The display changes to the next special function or back to your program set.
7. Press the OPTION key repeatedly, until your program set appears again.

Downloaded From WashingMachine-Manual.com Manuals

Child safety device

When the child safety device is set, the door can no longer be closed.

Setting the child safety device:
Use a coin to turn the knob (on the inside of the door) in a clockwise direction as far as it will go.



Warning! The knob must not be sunk-in after being set, otherwise the child safety device is not active. The knob must stand out as shown in the illustration.



Releasing the child safety device:
Turn the knob anti-clockwise as far as it will go.

Cleaning and maintenance

Important! Do not use furniture care products or aggressive cleaners to clean the appliance.
Wipe control panel and body with a damp cloth.

Cleaning procedure

If you plan to wash mainly at low temperature, you should run a hot programme from time to time. This will reduce any deposits and clean the appliance from the inside.

Downloaded From WashingMachine-Manual.com Manuals

Detergent dispenser drawer

The detergent dispenser drawer should be cleaned regularly.

1. Remove the detergent dispenser drawer by pulling it firmly.
2. Remove the conditioner insert from the middle compartment.
3. Clean all parts with water.
4. Put the conditioner insert in as far as it will go, so that it is firmly in place.



5. Clean all parts of the washing machine, especially the nozzles in the top of the washing-in chamber, with a brush.
6. Insert the detergent dispenser drawer in the guide rails and push it in.



Washing drum

Rust deposits in the drum may occur due to rusting foreign bodies in the washing or tap water containing iron.

Important! Do not clean the drum with acidic descaling agents, scouring agents containing chlorine or iron or steel wool.

1. Remove any rust deposits on the drum with a cleaning agent for stainless steel.
2. Run a washing cycle without any washing to clean off any cleaning agent residues. Program: LINEN/EASY-CARES 60°, option →| TIME SAVING: VERY SHORT, add approx. 1/4 of a measuring cup of washing powder.

Door and rubber collar

Regularly check whether deposits or foreign bodies are present in the folds of the rubber collar or on the inside of the glass door.
Clean the glass in the door and the rubber collar regularly.

Downloaded From WashingMachine-Manual.com Manuals

What to do if...

Remedying small malfunctions yourself

If while the appliance is operating a short acoustic signal sounds 3 times and one of the following messages appears in the display:
– „No incoming water/Check tap & Hose“,
– „No drain - check/drain hose/filter“ or “Pump Blocked”,
– “Door not Closed”,
please have a look at the following table.
When the fault is remedied, press the ⏀ START/PAUSE key.

If “Warning : E and number or letter” is displayed: Switch the appliance off and on again. Re-set the program. Press the ⏀ START/PAUSE key.

If the warning is displayed again, please contact the Customer Care Department and inform them of the warning.

Problem	Possible cause	Remedy
Washing machine does not work.	Mains plug not plugged in or fuse not working.	Plug in mains plug. Check fuse.
	Door not closed properly.	Close door - there should be an audible click.
	START/PAUSE key was not pressed for long enough.	Press START/PAUSEkey for longer.
Door cannot be closed.	Child safety device engaged.	Release child safety device.
Display shows: "Selection error".	The selected function cannot be combined with other program settings.	Make another selection.
Display shows: “Door not Closed/Please check”	Door not closed properly.	Close door - there should be an audible click. Start program again.
Display shows: “No incoming water/Check tap & Hose”	Tap turned off.	Turn the tap on.
	Filter in the screw connection of the inlet hose is blocked.	Turn off the water tap. Unscrew hose, take out filter and clean it.
	Water tap is blocked with limescale or faulty.	Check the water tap and have it repaired if necessary.

Downloaded From WashingMachine-Manual.com Manuals

Problem	Possible cause	Remedy
Washing machine vibrates when operating or is noisy.	Transit packaging has not been removed.	Remove transit packaging.
	Screw feet not correctly adjusted.	Adjust feet according to the Installation and Connection instructions.
Washing has not been spun.	Only a few large items of washing in the drum.	Always load the drum as full as possible. Mix large and small items.
Water is running out from under the washing machine.	Screw connection on the inlet hose is leaking.	Screw the inlet hose in firmly.
	Drain hose is leaking.	Replace drain hose.
	Drain pump cover is not closed properly.	Close cover properly.
	Washing was caught in the door.	Load washing carefully for the next wash.
	Emergency drain hose is leaking.	Close off emergency drain hose properly.
Display shows: "Warning : EF3". The drain pump runs constantly - even when the appliance is switched off.	The Aqua Control anti-flood system has responded.	Close the tap, remove the mains plug from the socket and inform Customer Service.
Display shows: "Excess Detergent"	Probably too much detergent has been used.	Dose detergent exactly as instructed by manufacturer.
Display shows: – "No drain - check drain hose/filter" or – "Pump Blocked"	Kink in drain hose.	Remove kink.
	Maximum pumping height of 1 m exceeded.	Please contact Customer Care Department.
	Drain pump is blocked.	Switch off appliance. Pull out mains plug. Clean drain pump. Remove foreign bodies from pump housing.
	With connection to sink outlet: Sink outlet is blocked.	Clean out sink outlet.
Fabric softener not rinsed in, ❀ compartment for additives is filled with water.	Conditioner insert in the compartment for additives is not correctly attached or is blocked.	Clean detergent dispenser drawer, insert conditioner insert firmly.

Downloaded From WashingMachine-Manual.com Manuals

Problem	Possible cause	Remedy
Door cannot be opened when appliance is switched on.	Door locked.	Wait until the display shows "Door openable" and "Cycle ended" alternately.
	Power cut. (All displays are off.) For safety reasons, the door remains locked for approx. 4 to 10 minutes.	Program continues, when power cut is over.
		To remove washing: If water can be seen in the appliance, before opening the door, first perform an emergency drain.
Washing is heavily creased.	Possibly too much washing was loaded.	Observe maximum loads.

If the wash results are not satisfactory

Washing is grey and scale is being deposited in the drum

- Too little detergent is being used.
- The right detergent was not used.
- Special soiling was not pre-treated.
- Programme or temperature was not correctly set.

There are grey stains on the washing.

- Washing soiled with ointment, grease or oil was washed with too little detergent.
- It was washed at too low a temperature.
- A common cause is that fabric conditioner – especially a concentrate – has got onto the washing. Such stains should be washed out as quickly as possible and make sure that you are careful when using fabric conditioner.

After the last rinse foam can still be seen.

- Modern detergents may create foam even in the last rinse cycle. The washing is however sufficiently rinsed.

There are white residues on the washing.

- This is due to the insoluble ingredients in modern detergents. They are not caused by insufficient rinsing.
  Shake or brush the washing. If possible turn the washing inside out before washing. Check your choice of detergent. Especially with dark colours it is advisable to use liquid detergents.

Downloaded From WashingMachine-Manual.com Manuals

Carrying out an emergency drain

Warning! Before emergency draining, switch off the washing machine and remove the mains plug from the socket.

Warning! The water that comes out of the emergency drain hose may be hot. There is a risk of scalding. Let the water cool before performing an emergency drain.

1. Open the plinth flap and remove it.



2. Take out the emergency drain hose.



3. Place a shallow container underneath it. Then loosen the drain plug by turning it in an anti-clockwise direction and pull it out.
4. The water runs out. If it is necessary to empty the container more than once, seal up the emergency drain hose with the drain plug while you are doing so.



When the water has all drained away:

5. Push the drain plug firmly into the emergency drain hose and screw it tight in a clockwise direction.
6. Place the emergency drain hose back in the support.
7. Insert the plinth flap and close it.

Downloaded From WashingMachine-Manual.com Manuals

Drain pump

The drain pump is maintenance-free. It is only necessary to open the pump cover if there is a malfunction and water is no longer being pumped out, e. g. if the pump wheel is blocked.
Please make sure before loading the washing that there are no foreign bodies in the pockets or caught between the washing. Paperclips, nails, etc. that may have got into the washing machine with the washing remain in the pump housing (foreign body trap that protects the pump wheel).

Warning! Before opening the pump cover, switch off the washing machine and remove the mains plug from the socket.

1. First carry out an emergency drain.
2. Place a cloth on the floor in front of the drain pump cover. Residual water runs out.
3. Unscrew the pump cover in an anti-clockwise direction and remove it.



4. Remove foreign bodies and fluff from the pump housing and from the pump wheel.



5. Check whether the pump wheel right at the back of the pump housing can turn. (It is normal for the pumping wheel to turn jerkily.) If the pumping wheel cannot be turned, please contact the Customer Care Department.



6. Insert the pump cover. Insert the guides at the sides of the cover into the guide slots and tighten the cover by turning in a clockwise direction.



7. Close off the emergency drain hose and place it in the support.
8. Close plinth flap.

Downloaded From WashingMachine-Manual.com Manuals

Disposal

Packaging material
The packaging materials are environmentally friendly and can be recycled. The plastic components are identified by markings, e.g. >PE<, >PS<, etc. Please dispose of the packaging materials in the appropriate container at the community waste disposal facilities.

Old appliance

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Warning! When an appliance is finished with, remove the plug from the mains socket. Cut off the cable and plug and dispose of them. Destroy the door lock. This prevents children from trapping themselves inside and endangering their lives.

Downloaded From WashingMachine-Manual.com Manuals

Technical data

CE This appliance conforms with the following EU Directives:
– 73/23/EEC dated 19.02.1973 Low Voltage Directive
– 89/336/EEC dated 03.05.1989 EMC Directive inclusive of Amending Directive 92/31/EEC
– 93/68/EEC dated 22.07.1993 CE Marking Directive

Height x Width x Depth	850 x 598 x 640 mm
Depth when door is open	1017 mm
Height adjustment	approx. +10/-5 mm
Load (depending on programme)	Max. 6 kg
Area of use	Domestic
Drum spin speed	see programme overview
Water pressure	1-10 bar (=10–100 N/cm^2=0.1–1.0 MPa)

Consumption values

The consumption values were obtained under standardised conditions. They may vary when operating in domestic conditions.

Program knob/ Temperature	Type of fabric	Load in kg[1)]	Water in litres	Energy in kWh
ECO ENERGY SAVING [2)]	Cotton	6	39	1,02
95 COTTON 95	Cotton	6	54	2,10
LINEN/EASY-CARES 40 STAIN [2)]	Cotton	6	52	0,75
LINEN/EASY-CARES 40 [2)]	Synthetics	3	52	0,52
DELICATE 30	Synthetics	3	56	0,40
WOOL (HANDWASH) 30	Wool	2	50	0,35

1) The load is determined in accordance with EN 60456 Standard Loads.
2) **Note:** Program setting for testing in accordance with or in support of EN 60 456 and IEC 60 456.
Actual consumption will vary from the indicated values depending on water pressure, water hardness, water temperature at filling, room temperature, type and quantity of washing, detergent used, variations in mains voltage and any additional program functions selected.

Downloaded From WashingMachine-Manual.com Manuals

⚠ Safety information for the installation

- This washing machine **cannot be built-in**.
- Before using for the first time, check the appliance for damage sustained while it was being transported. Do not under any circumstances connect an appliance that is damaged. In the case of damage, please contact your supplier.
- Before using for the first time, all parts of the transport lock must be removed. Otherwise when spinning damage may be caused to the appliance or to neighbouring units or furniture.
- Before using the appliance for the first time, splash protection must be completed. (See "Removing the transit packaging".)
- Always plug the mains plug into a correctly installed shockproof socket.
- Permanent connection: a permanent connection must only be installed by a trained electrician.
- Prior to using the appliance for the first time, ensure that the rated voltage and type of supply on the rating plate match that of the supply where the appliance is to be installed. The fuse rating is also to be found on the rating plate.
- If work on the plumbing is required for the proper connection of the washing machine to the water supply, this must be undertaken by a competent person.
- If work on the electricity supply system is required for the proper connection of the washing machine to the electricity supply, this must be undertaken by a registered electrician.
- The washing machine's cable must only be replaced by the Customer Care Department or a registered electrician.

Downloaded From WashingMachine-Manual.com Manuals

Installing the appliance

Transporting the appliance

Warning! The washing machine is very heavy. Risk of injury. Be careful when lifting.

- Do not lay the appliance on its front nor on its right side (as seen from the front). Electrical components may get wet.
- Never transport the appliance without its transport lock. Only remove the transport lock when the appliance is in its place of installation. Transporting the appliance without its transport lock can lead to damage to the appliance.
- Never lift the appliance by the door when it is open nor by the plinth.

When moving using a sack trolley:

- Only use the sack trolley on the side of the appliance. The sack trolley's base plate must not be longer than 24 cm, otherwise parts of the anti-flood system may be damaged.

Unpacking

The transport safeguard must be removed before putting the appliance into operation.

Important!

You are advised to keep all the packaging for re-use in case the machine is to be transported again.

1. After removing all the packaging, with assistance carefully lay machine on it's back to remove the polystyrene base from the bottom.



Downloaded From WashingMachine-Manual.com Manuals

2. Remove the power supply cable and the draining hose from the hose holders on the rear of the appliance.



3. With a suitable spanner unscrew and remove the central rear bolt **A**. Slide out the relevant plastic spacer.



4. Unscrew and remove the two large rear bolts **B** and the six smaller bolts **C**.



Downloaded From WashingMachine-Manual.com Manuals

5. Remove the bracket **D.**



6. Refit the six smaller bolts **C**.



7. Open the porthole and remove the polystyrene block fitted with the adhesive tape on the door seal.



8. Fill the smaller upper hole and the two large ones with the corresponding plastic plug caps supplied in the bag containing the instruction booklet.

Important!
All the different plug caps are supplied with the appliance in the plastic bag containing the instruction booklet.



Downloaded From WashingMachine-Manual.com Manuals

Connect the water inlet hose as described under the paragraph “Water inlet”.

Where to install

Important! The appliance must not be used in a room where there is a danger of frost. Frost damage or impaired operation! Frost damage is not covered by the warranty.

- The surface on which the appliance is to be installed must be firm and level. Do not install the appliance on carpets or on soft floor coverings.
- The surface on which the appliance is to be installed must be clean and dry and free from coverings that move, so that the appliance does not slide.
- If the location in which the appliance is to be installed is fitted with small-format tiles, put a rubber mat (available in the shops) under the appliance.

Making the appliance level

The four feet of the appliance are pre-adjusted.
Large degrees of unevenness can be compensated for by individually adjusting the height adjustable screw feet.
Use the special spanner supplied to do this.

Important! Do not use pieces of wood, cardboard or such like to level out unevenness in the floor, but adjust the height adjustable screw feet instead.



Electrical connection

Details about the voltage, type of supply and the fuses required are to be found on the rating plate. The rating plate is next to the doorway.

Downloaded From WashingMachine-Manual.com Manuals

Connecting to the water supply

Permitted water pressure

The water pressure must be at least 1 bar (= 10 N/cm^2 = 0.1 MPa) and may be a maximum of 10 bar (= 100 N/cm^2 = 1 MPa).

– If more than 10 bar: Connect a pressure reduction valve.
– If less than 1 bar: Disconnect the appliance end of the inlet hose from the solenoid inlet valve and remove the flow meter. (In addition remove the filter using pointed pliers and take out the rubber gasket behind it.) Re-insert the filter.

Water inlet

Attention!

- An inlet hose is supplied and can be found inside the machine drum.
- **Do not use the hose from your previous machine to connect to the water supply.**
- **This appliance must be connected to a cold water supply.**

1. Open the porthole and extract the inlet hose.
2. Connect the hose with the angled connection to the machine.

   Important!
   Do not place the inlet hose downwards. Angle the hose to the left or right depending on the position of your water tap.
3. Set the hose correctly by loosening the ring nut. After positioning the inlet hose, be sure to tighten the ring nut again to prevent leaks.



Downloaded From WashingMachine-Manual.com Manuals

4. Connect the hose to a tap with a 3/4" thread.
Always use the hose supplied with the appliance.



Installation should comply with local water authority and building regulations' requirements.
A minimum water pressure of 0.05 MPa (0.5 bar) is required for safe operation of the appliance.
If you cannot make the cold water connection direct from the rising mains, you may be able to operate the appliance from your cold water storage system.
There should be a minimum distance of 5.02m (16.5 ft) between the appliance's inlet and the bottom of the water storage tank.

Aqua Control

The inlet hose is provided with a water stop device, which protects against damage caused by water leaks in the hose which could develop due to natural ageing of the hose. This fault is shown by a red sector in the window „**A**". Should this occur, turn the water tap off and refer to your Service Centre to replace the hose.



Downloaded From WashingMachine-Manual.com Manuals

Water drainage

The maximum permitted difference between the height of the surface on which the appliance is installed and the water outlet is 1 metre.

Only original hoses may be used to extend hoses. (A maximum of 3 m laid on the floor and then 80 cm vertically). The Customer Care Department stocks outlet hoses of different lengths.

Draining water into a sink outlet

Secure the outlet/sink outlet joint with a hose band clip (available from your dealer).



Draining water into a wash basin/bath

Important!

- Small basins are not suitable. Water may overflow.
- The end of the drain hose must not be in the water that has been pumped out. Otherwise water could be sucked back into the appliance.
- When draining into a wash basin or a bath, secure the drain hose with the supplied elbow to stop it slipping. Otherwise the water running out can force the hose out of the basin.
- When pumping the water out, check that the water is running away fast enough.





Pumping heights over 1 m

The washing machine's drain pump is able to pump water to a height of 1 meter, calculated from the surface on which the appliance is installed.

Warning! If pumping height is over 1 metre, malfunctions and damage to the appliance may arise.

For pumping heights over 1 metre a conversion kit can be obtained. Please contact the Customer Care Department.

Downloaded From WashingMachine-Manual.com Manuals

Guarantee/Customer Service

European Guarantee

This appliance is guaranteed by Electrolux in each of the countries listed at the back of this user manual, for the period specified in the appliance guarantee or otherwise by law. If you move from one of these countries to another of the countries listed below the appliance guarantee will move with you subject to the following qualifications:

- The appliance guarantee starts from the date you first purchased the appliance which will be evidenced by production of a valid purchase document issued by the seller of the appliance.
- The appliance guarantee is for the same period and to the same extent for labour and parts as exists in your new country of residence for this particular model or range of appliances.
- The appliance guarantee is personal to the original purchaser of the appliance and cannot be transferred to another user.
- The appliance is installed and used in accordance with instructions issued by Electrolux and is only used within the home, i.e. is not used for commercial purposes.
- The appliance is installed in accordance with all relevant regulations in force within your new country of residence.

The provisions of this European Guarantee do not affect any of the rights granted to you by law.

Downloaded From WashingMachine-Manual.com Manuals

www.electrolux.com

Albania	+35 5 4 261 450	Rr. Pjeter Bogdani Nr. 7 Tirane
Belgique/België/ Belgien	+32 2 363 04 44	Bergensesteenweg 719, 1502 Lembeek
Česká republika	+420 2 61 12 61 12	Budějovická 3, Praha 4, 140 21
Danmark	+45 70 11 74 00	Sjællandsgade 2, 7000 Fredericia
Deutschland	+49 180 32 26 622	Muggenhofer Str. 135, 90429 Nürnberg
Eesti	+37 2 66 50 030	Mustamäe tee 24, 10621 Tallinn
España	+34 902 11 63 88	Carretera M-300, Km. 29,900 Alcalá de Henares Madrid
France	www.electrolux.fr	
Great Britain	+44 8705 929 929	Addington Way, Luton, Bedfordshire LU4 9QQ
Hellas	+30 23 10 56 19 70	4 Limnou Str., 54627 Thessaloniki
Hrvatska	+385 1 63 23 338	Slavonska avenija 3, 10000 Zagreb
Ireland	+353 1 40 90 753	Long Mile Road Dublin 12
Italia	+39 (0) 434 558500	C.so Lino Zanussi, 26 - 33080 Porcia (PN)
Latvija	+37 17 84 59 34	Kr. Barona iela 130/2, LV-1012, Riga
Lietuva	+370 5 2780609	Verkių 29, LT-09108 Vilnius
Luxembourg	+352 42 431 301	Rue de Bitbourg, 7, L-1273 Hamm
Magyarország	+36 1 252 1773	H-1142 Budapest XIV, Erzsébet királyné útja 87
Nederland	+31 17 24 68 300	Vennootsweg 1, 2404 CG - Alphen aan den Rijn
Norge	+47 81 5 30 222	Risløkkvn. 2 , 0508 Oslo
Österreich	+43 18 66 400	Herziggasse 9, 1230 Wien
Polska	+48 22 43 47 300	ul. Kolejowa 5/7, Warsaw
Portugal	+35 12 14 40 39 39	Quinta da Fonte - Edificio Gonçalves Zarco - Q 35 2774 - 518 Paço de Arcos
Romania	+40 21 451 20 30	Str. Garii Progresului 2, S4, 040671 RO
Schweiz/Suisse/ Svizzera	+41 62 88 99 111	Industriestrasse 10, CH-5506 Mägenwil

Downloaded From WashingMachine-Manual.com Manuals

Slovenija	+38 61 24 25 731	Electrolux Ljubljana d.o.o. Gerbiceva 98, 1000 Ljubljana
Slovensko	+421 2 43 33 43 22	Electrolux Slovakia s.r.o., Electrolux Domáce spotrebiče SK, Seberíniho 1, 821 03 Bratislava
Suomi	www.electrolux.fi	
Sverige	+46 (0)771 76 76 76	Electrolux Service, S:t Göransgatan 143, S-105 45 Stockholm
Türkiye	+90 21 22 93 10 25	Tarlabaşı caddesi no : 35 Taksim Istanbul
Россия	+7 095 937 7837	129090 Москва, Олимпийский проспект, 16, БЦ „Олимпик“

Downloaded From WashingMachine-Manual.com Manuals

Service

In the event of technical faults, please first check whether you can remedy the problem yourself with the help of the operating instructions (section “What to do if...”).

If you were not able to remedy the problem yourself, please contact the Customer Care Department or one of our service partners.

In order to be able to assist you quickly, we require the following information:



– Model description
– Product number (PNC)
– Serial number (S No.)
  (for numbers see rating plate)
– Type of fault
– Any error messages displayed by the appliance

So that you have the necessary reference numbers from your appliance at hand, we recommend that you write them in here:

Model description: .....

PNC: .....

S No: .....

Downloaded From WashingMachine-Manual.com Manuals

www.electrolux.com

Downloaded From WashingMachine-Manual.com Manuals